



IIIu	s. Part		lllus.	Part		IIIus	. Part	
No	o. No.	DESCRIPTION	No.	No.	DESCRIPTION	No.		DESCRIPTION
								(5. (1.)
1		LITERATURE PARTS	10		Clip, Wire	29	0000770	Hinge (Bottom)
		Use & Care Guide	11	1112849	Cap, Grommet			Freezer Side
		Energy Label	12	2209022	Housing, Water	مم ا		Refrigerator Side
	LIT2209309	Service & Wiring	4.0	4440400	Filter	30	2004992	
		Sheet	13		Grommet, Wiring		0004445	Adjustable
	LIT628370		14	2209059	Wiring Harness,	31	2001415	
		Service Sheet			Cabinet	32		Skirt-Grille,
	LIT2209250		15		Filter, Water		0000004144	Bottom
		Instructions	16		Tube, Clamp		2209024W	White
			17		Screw, Door Stop		2209024B	
2		Cabinet (Not A	18		Hinge (Top)	م ا	2209024T	
		Serviceable Part)	20	489464		33	2004516	Linkage, Door
3	2005004	Grommet, Tube	21	2004994	Lock, Adjustable	۱ 🔐		Closure
		Crossover			Bushing	34		Grille Base,
4	1112023	,	22	2002903			0000405\4	Front
		Rear (4)	23	2209090	Clamp, Filter		2209425W	
5		Support, Leveler			Housing		2209425B	
		Assembly	24	2004567	Spring, Door		2209425T	
		Refrigerator Side			Closure	36		Cover, Rear
		Freezer Side	25	486194		37		Grommet, Wiring
6		Grommet, Wiring	26	2005008	Retaining Ring,	39	2006346	
7	2005007	Grommet,			Adjustable Bushing	40	2004565	Bushing, Door
		Flexible	27		Fastener (3)	۱ ,,	4400000	Closure
8		Cap, Water Filter	28	2006342	Gap, Cover	41	1163283	
	2186494W	White			Assembly (Bottom)	42	2196152	
	2186494B					43	2001415	Screw (4)
_	2186494T							
9	2006442	Mounting Stud,						
		Grill	ı			ı		

CABINET TRIM PARTS




FREEZER LINER PARTS



Illus. No.	Part No.	DESCRIPTION
1		Liner (Not A
		Serviceable Part)
2	2005567	Bracket, Light
3	1113650	Lens
4	2005042	Light, Socket
5	548049	Light, Bulb
6	538533	Support Clip,
		Icemaker (2)
7	2000193	Grommet, Screw (2)
8	488552	Screw
12	486194	
13	1112591	Spacer, Control
		Panel (3)
14	842534	Clip, Air Duct (4)
16	1112260	Support,
		Evaporator
17	2004068	Stud, Shelf (20)
18	487559	Screw


REFRIGERATOR LINER PARTS



REFRIGERATOR LINER PARTS


Part No.	DESCRIPTION
	LINER (Not A
	Serviceable Part)
1112591	Spacer, Control
	Panel (3)
2001117	Ladder, Shelf (2)
520965	Screw Support,
	Ladder (8)
488357	Screw
	Screw
	Hole Plug
2188392	Meat Pan, Air
	Duct Cover
	Meat Pan, Air Duct
	,
1112218	Damper Control,
0000011	Meat Pan
2003811	Control Knob,
0000044	Meat Pan
	Retainer, Knob
2004484	Air Baffle
2200006	Assembly
	Diffuser Assembly
	Cover, Thermistor Thermistor
	Cover, Diffuser
	Guard, Air Return
	No. 1112591 2001117 520965

REFRIGERATOR CONTROL PANEL PARTS




Illus. No.	Part No.	DESCRIPTION			
1	2209225	Control Panel			
2	2209001				
3	2208995	Circuit Board			
4	2003842	Control Knob			
5	2003841	Retainer, Knob			
6	1118894				
7	1113133				
		Panel			
8	489260	Screw (3)			
9	2000153				
10	2209172	Shield, Control			
		Panel			
11	2005043	· · · · · · · · · · · · · · · · ·			
12	548049	3 ' ' ' ' '			
13	486194				
14	2006223	-, 3			
15	2001141	Channel, Wiring			
16	1115375	- ·· - , · · · · · · · · · · · · · · · · · ·			
17	2200096	Lens, Indicator			
40	0000007	Light			
18	2200097				
19	2203384	Circuit Board, Filter Indicator			
20	489214	Screw			

FREEZER CONTROL PANEL PARTS



Illus. No.	Part No.	DESCRIPTION
1		Control Panel
2	2003307	Inlay, Control
		Panel
3	1113466	Thermostat &
		Barrier Assembly
4	488974	Screw (2)
5		Switch, Rocker Arm
6		Seal, Control
		Panel
8	489260	Screw (3)
9	2000153	
10		Shield, Control
. •		Panel
11	2005042	Socket, Light
12	486194	, 0
13	548049	
14		Channel, Wiring
16		Knob, Thermostat
17	1115375	Clip. Wiring


REFRIGERATOR SHELF PARTS



REFRIGERATOR SHELF PARTS
For Models: KSSS36QJW00, KSSS36QJB00, KSSS36QJT00
(White) (Black) (Biscuit)


Illus. No.	Part No.	DESCRIPTION
1	2174402	Frame, Shelf
2	2003375	
2 3 4	1113546	Reflector, Shelf
	1113790	Gasket, Glass (2)
5	2179375	Rack, Wine
6	2169933	Egg Bin
7	2006523	Frame, Assembly
		Meat Pan
8	2164373	Egg Carrier
9	1113893	Cover, Crisper
10	2003378	- · · · · · · · · · · · · · · · · · · ·
11	2000742	Meat Pan,
		Connector
12	2169935	
14	2006544	1 ()
15	2188212	Roller
16	2174478	Eyelet, Roller
17	2003478	
20	2006529	
23	2002181	Retainer, Glass
25	2003411	Crisper Spacer,
07	4440400	Right Side (2)
27 28	1113169 2003410	Stop, Roller
20	2003410	Crisper Spacer,
29	486194	Left Side (2) Screw
20	100104	

FREEZER SHELF PARTS




Illus. No.	Part No.	DESCRIPTION
1	2003142	Solid Shelf
2	2188381	Front, Ice
		Compartment
3	1113564	Shelf, Fixed (1)
	1113636	Shelf, Deep (2)
4	2208192	Basket
5	2003112	Trim, Basket
6		Slide, Basket
	2208198	
	2208197	Left Side
7	486194	Screw

TOP GRILLE AND UNIT COVER PARTS



Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1 2 3 4 5 6	486194	Black Biscuit Cover, Unit Screw Grille, Bracket Screw Decortive Panel Assembly White Black	7 8 10		Biscuit Trim, Grille Top White Black	12 13 14 15	2003602 2005821 2005732 2003608 2005824 2005733 2003347 1161548	Black Biscuit Trim, Grille Left Side White Black Biscuit


MOTOR AND ICE CONTAINER PARTS



MOTOR AND ICE CONTAINER PARTS


Illus. No.	Part No.	DESCRIPTION				
1	2003939	Bracket, Motor				
2	2155263	Motor, Dispenser				
3	2003979	Soleniod Assembly				
4	2149100	Guide, Solenoid				
5		Slide, Container				
	2002720	Right Side				
_	2002721	Left Side				
6	1113169	Stop, Roller				
7	2004006	Wiring Assembly,				
0	400000	Ice Dispenser				
8	489399	Screw				
9 10	2205716 489478	Coupling, Motor Screw				
12	1113128	Cover, Motor				
13	486194	Screw				
14	2208906	Ice Container				
15	983668	Coupling, Conveyor				
18	1119005	Spacer, Step (3)				
19	1119007	Spacer, Flat (2)				
20	1119006	Blade, Rotary				
21	1119012					
22	1119013	Blade, Rotary				
23	489235					
24	1119009					
25	2157405	Block, Blade				
26	489229	Roll Pin				
27	2160602	Conveyor				
28	2196194	Drum				
29	3400912	Washer				
30	2171682	Floating Baffle				
31	1119018	Nut, Bearing				
32 33	2002728	Control Arm Spring, Return				
34	1119020 1119021	Retainer Clip, Rod				
35	488886	Screw				
36	2188212	Roller				
37	2180348	Housing, Crusher				
38	1119017	Deflector, Ice				
39	489234	Washer, Plain				
40	489236	Retainer Ring				
43	2174478	Eyelet, Roller				
44	2002722	Front Cover,				
		Ice Container				
47	2003478					
99	2160606	Complete Ice				
		Crusher Mechanism				
		Assembly				
100	2006541	Complete Ice				
		Container Assembly				

REFRIGERATOR DOOR PARTS



REFRIGERATOR DOOR PARTS

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	2003870	Door Panel (Includes	11	2005953 2005956		19	2003666 2005880	
2	939101 2005329	Insulation) Screw Anchor (8) Hinge Assembly,	12 13	2005955 2001230 2004549	Washer	20	2005743 1113952	Panel, Interior Door
4	2004520	Тор	15	2004349	Bottom Screw, 8–15 x .500	21 22		Ladder, Shelf (2) Retainer, Shelf
5 6	489282	Top Screw Hinge Assembly,		2001208 3400878	Black	23 24	1112514 486194	Ladder (2) Back Up Plate (8)
7	1112533	Bottom	16	3400877 2005013	Trim (Top)	25 26	1112720	Bin, Utility Door, Utility Bin
8	1112539	Side (2) Gasket Retainer, Top & Bottom	40	2005839 2005740	Biscuit	27 28 29		Door Shelf Butter Tray Retaining Ring,
9	2188319		18	2005968 2005971 2005970	Trim (Side) White Black Risquit	30	2188331	Door-Closure




FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

FREEZER DOOR PARTS
For Models: KSSS36QJW00, KSSS36QJB00, KSSS36QJT00
(White) (Black) (Biscuit)

Illus. No.	. Part No.	DESCRIPTION
1		Freezer Door
		Panel (Includes
	0000540\4/	Insulation)
	2202546W	
	2202546B 2202546T	
4	2004881	Biscuit Retaining Ring,
4	2004001	Door-Closure
6	2004524	Hinge, Bottom
7	489282	
8	2005329	
9	2004520	Spacer-Door,
		Тор
12	1112533	Gasket Retainer,
		Side (2)
13	1112538	Gasket Retainer,
		Top & Bottom
14	2188317	Door Gasket,
4.5	400404	Magnetic
15 16	486194	
10	2005943	Handle, Door White
	2005946	
	2005945	
18	2004549	
20	_00.0.0	Screw
	2001208	
	3400878	
	3400877	Biscuit
21		Trim (Top)
	2005022	
	2005885	
00	2005746	
23	2004660	Trim (Bottom) White
	2004669 2005888	
	2005000	Biscuit
24	2000141	Trim (Side)
	2005963	White
	2005966	Black
	2005965	Biscuit
26	2209027	Panel, Interior
		Door
28	2209163	
29		Trim, Endcap
	2208954	Left Side
2.4	2209134	Right Side
34	2208909	Ice Chute


DISPENSER FRONT PARTS



DISPENSER AND FRONT PARTS

Illus.	Part		Illus.	Part		Illus		
No.	No.	DESCRIPTION	No.	No.	DESCRIPTION	No.	No.	DESCRIPTION
1		Housing, Dispenser	19	489000		45		Trim, Front (2)
•	040=0=4	(Not Serviceable)	20		Lever, Water		2208917	White
2	2195051				Dispenser		2208926	
10		Spring, Torsion		2180268			2208923	Biscuit
11	2196195			2180270		47		Grille, Overflow
12		Ice Door Mechanism		2186852			2180323	White
13		Door, Ice	22		Spring, Lever		2180325	Black
16	489000		24		Delay Mechanism		2186860	
17		Lever, Ice	25		Bracket, Control	49		Overlay, Cover
	0400050	Dispenser	26		Switch (2)		2202573	
	2180259	White	27		Insulation, Switch		2202576	
	2180261	Black	29		Lamp Holder		2202579	
40			30		Screw	53		Washer (2)
18	2202551	Switch Assembly	36		Wire Assembly	54	488568	Screw (2)
		(Also Order	37		Guide, Ice	55		Front Cover
		Item #49)	40	487052	=			Assembly
			41	3406124	Light Bulb			(Includes Items
								18, 36, 42, & 49)
							2202570W	White
							2202570B	
						l	2202570T	Biscuit

UPPER UNIT PARTS




UPPER UNIT PARTS

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1 2	2163787	Assembly, Unit Base Clip, Compressor Mounting (4)	21 23 24 25	2190685	Drier Motor, Fan Blade, Fan Orifice, Fan		-	arts Not Illustrated Parts Not Included
3	2183418	Compressor (Includes Items 8, 9, 11,12 & 21) (Also Order 876765 Tube Kit)	27 29 30 31 32	486692			978026	Valve, Access (1/4") Valve, Access (5/16") Valve, Access
4 6 8 9	2163786 2154760	Washer Grommet, Mounting Overload Terminal Cover	34 35 36	2003011 487869	Condenser Process, Tube		978028	(3/8") Valve, Access (1/2") Valve, Access
11 12 14 15 16	486899 487869	Capacitor Screw	37 39 41 42	2003381 1113162	Cover, Condenser Service Cord Clamp, Cord (2) Switch, Power Disconnect		978030	(5/8") Valve, Access (3/4") Valve, Access
17 18 19 20	943447 1113019 487522	Grommet (4) Clamp (4)	43 44 45	653035	Screw, Ground Clip, Cord Plug Wiring Harness, Unit Compartment	REFF	RIGERA	(3/16") NT CHARGE 7.0 oz. (R–134A)




LOWER UNIT AND TUBE PARTS



LOWER UNIT AND TUBE PARTS

Illus.	Part	
No.	No.	DESCRIPTION
•		
1	2006755	Defrost Bi-Metal
2	1113043	,
2 3 4	486194	
	2003271	
5	2002171	
6	2002999	Condenser
_		Inlet Tube
7	2003484	
8	2003015	Tube, Connect
_		(Drier)
9	2004545	Heater, Drain Pan
10	1113062	Hanger, Heater
11	2005908	Shield-Drain, Pan
12	2002448	Sleeve
13	2002995	Tube, Discharge
14	2003272	Sleeve
15	2003001	Heat Exchanger
16	2002964	Evaporator
17	2006749	Heater, Defrost
18	1113048	Clamp, Heater (2)
19	1108431	Clamp, Heater (2)
20	1112844	Gasket, Evaporator
21	857547	Wire Tie
23	851095	
25	2001264	Drain Pan
26		Bracket, Drain Pan
	1113206	Left
	1113207	Right
27	513942	Dampener

AIR FLOW AND RESERVOIR PARTS
For Models: KSSS36QJW00, KSSS36QJB00, KSSS36QJT00
(White) (Black) (Biscuit)




AIR FLOW AND RESERVOIR PARTS For Models: KSSS36QJW00, KSSS36QJB00, KSSS36QJT00

(White) (Black) (Biscuit)

IIIus. No.	Part No.	DESCRIPTION				
1	2003200	Fan Motor				
2	2002732	Cup, Clearance				
3	2169142	Fan Blade				
4	548263	Bracket (Double)				
5	938224	Bracket (Single)				
6	548268	Grommet				
7	486194	Screw				
8	2003924	Deflector,				
9	488500	Air Duct Screw, Ground				
10	488366	Clamp, Tube				
11	488937	Clamp, Nylon				
12	2001145	Channel, Wiring				
13	1112871	Fastner				
14	2000783	Scroll, Fan				
15	2003927	Deflector,				
		Air Duct				
17	2208900	Assembly, Air Duct				
		(Also Order				
40	0400440	Items 8 & 15)				
18	2182146	Air Deflector, Icemaker				
22	1112869	Gasket, Air Baffle				
23	2003576	Cover, Air Outlet				
25	2005076	Cover, Evaporator				
26	2000797	Connector, Meat				
_		Pan Duct				
27	487539	Screw				
28	1112840	Baffle, Evaporator				
29	1112851	Diffuser, Air Duct				
30	2209687	Reservoir				
31	488280	Screw				
42		Evaporator, Cover Rail				
	2000686	Left Side				
	2000685	Right Side				
45	2001337	Gasket (2)				
. •		Evaporator Cover				
46	2001079	Gasket (2)				
47	2001080	Gasket				
48	2001081	Gasket				

ICEMAKER PARTS



ICEMAKER PARTS

For Models: KSSS36QJW00, KSSS36QJB00, KSSS36QJT00 (White) (Black) (Biscuit)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
3	2203198	Tube, Filter	18	2174155	Cover	30	489276	Screw
		Inlet	20		Mold & Heater	31		Shut Off Arm
4	841707	Insert, Tube	20	020220	(Also Order	33	2171952	
5	628379	Clip, Fuse			542638 Silicone	34	489478	
6	2209430	Tube, Filter			Grease)	35		Module Assembly
		Outlet	21	628398	,		020000	(Includes Items
7	2208933	Water Inlet	22		Cup-Water Fill			21 & 41)
		Tube Assembly	23	2194711	•	36	2185988	Fitting, Water
8	1106508	Seal Gasket	24		Ice Striper		2100000	Tube
9	2154472	Connector	25	2194712		37	2004914	
10	2006766	Valve, Solenoid	26		Retainer	01	2004514	Mounting Bracket
11	627018	Nut, Compression	20	021130	Thermostat (2)	41	489136	Screw (2)
12	227991	Connector, Wire	27	627985	` ,	43	486194	` ,
13	2209072	Water Valve,	"	027303	(Also Order	44		Compresion Nut
		Harness			542639 Cement	100		Complete Icemaker
15	2208136	Clamp, Nylon			Alumilastic)	100	4017540	Assembly
		Valve	28	489322				7.00Cilibry
16	488937	Clamp Tube	20	+03322	COLCAN			
		•						

PARTS NOT ILLUSTRATED

Illus.	Part	
No.	No.	DESCRIPTION

Following Parts Not Illustrated (Optional Parts Only)

4378650 Front Panel Kit (White)
4378653 Front Panel Kit (Black)
4378656 Front Panel Kit (Almond)
4378659 Front Panel Kit (Stainless Steel)
4392886 Front Panel Kit (Biscuit)

Black Acrylic

Static Ćleaner Part No. 978849